


Errata Sheet

This document amends the Operations Manual.

Icon	Description
	<p>This symbol indicates that the area access can cause risks to persons wearing a pace-maker.</p> <p>Any person with a pace-maker must keep a safety distance of at least 200 mm from the module axes.</p>